

820-0231 – Install Instructions for Chilled Air Blower Mixing Valve (P/N: 205-0121-03) GE P/N: 5156323

Tools Required:

- 10 foot ladder
- (2) Slip lock pliers
- Slip wrench
- Utility knife
- Insulated foam tape

Removal Procedure:

1. Perform shutdown of system in accordance with Lytron manual #820-0190.
2. Lockout/Tag out system in accordance with GE procedures.
3. Drain system. Drain system in accordance with Lytron manual #820-0190.
4. Disconnect the 5 pin connector to the valve.
5. Remove insulation around either side of mixing valve using a utility knife or equivalent. (Refer to photo 1)



Photo 1

6. Remove the exhaust manifold (Port A) of the mixing valve by using a slip wrench. The nut will remain on the manifold. (Refer to photo 2)



Photo 2

7. Remove exhaust manifold (Port AB) of the mixing valve by using a slip wrench. The nut will remain on the manifold. (Refer to photo 2)
8. Remove the exhaust manifold (Port B) of the mixing valve by using a slip wrench. The nut will remain on the manifold. (Refer to photo1)

9. Remove the valve.
10. Repeat Steps 4 thru 9 to remove PE mixing valve.

End of Procedure

Install Procedure:

1. Mate the new valve to the manifold (Port B). Be careful to make it flush with the manifold.
2. Tighten nut with 1/1/2" wrench and slip lock pliers.
3. Repeat procedure for manifolds connecting to Port A and Port AB (as marked on the mixing valve).
4. Wrap each connection with insulated tape.
5. Connect 5 pin connector to appropriate control plug.
6. Refill system in accordance with Lytron manual #820-0190.
7. Clear Lockout/Tag out for the system in accordance with GE procedures.
8. Restart system.

End of Procedure